

Peristaltic Tube Assembly Care and Use Guide

- **Blue-White Tube Assemblies are specifically designed, tested, and intended for use only in Blue-White peristaltic pumps.** Users assume the risk of using Blue-White Tube Assemblies for any other purpose.
- **Blue-White peristaltic metering pumps are designed to operate with Tube Assemblies manufactured by Blue-White only.** Use of tubing not manufactured by Blue-White will affect the pump's performance, may damage the pump, and will void the warranty.
- Blue-White Tube Assemblies are designed to function in a specific pump model. Verify that the Tube Assembly used is compatible with the pump before installing.
- There are a variety of Blue-White Tube Assembly options available for each peristaltic pump. **Verify that the Tube Assembly selected is suitable for the application before use.** It is possible the Tube Assembly provided with the pump may not be the best option for your specific application. Review your application before using the pump. Any change in chemical, flow, pressure, duty, or piping will require re-evaluating the Tube Assembly's fit for purpose.
- We recommend keeping spare Tube Assemblies on site, as the Tube Assemblies are wearable parts and will need periodic replacement. Keep all spare Tube Assemblies in the original packaging and store them in a clean, dry, and temperature-controlled environment out of direct sunlight. Flex-A-Prene and Flex-A-Chem Tube Assemblies have a shelf life of 3 years. Flex-A-Thane Tube Assemblies have a shelf life of 1 year.
- Tube Assembly life is highly dependant on pump speed, pressure, and duty. Tube Assemblies may last only a few days/weeks, or can last longer than a year in a specific application. However, Tube Assemblies should be replaced at least once a year. An estimate of Tube Assembly life for a specific application can be provided by contacting the Blue-White factory.
- Contact the Blue-White factory immediately if you are unsure about the use and operation of any Tube Assemblies.

P.N. #80000-732 REV 0.9 20240201



**ISO 9001:2015
CERTIFIED**

**MADE IN THE
USA**

Have Questions?

Contact us

+1 (714) 893-8529
customerservice@blue-white.com



blue-white.com/contact-us