**Operating Manual** 



# CHEM-FEED®

Industrial Skid Systems



# **Series CFS**

# TABLE OF CONTENTS

Section	Heading	<u>Page</u>
1.0	Introduction	2
2.0	Specifications	3
3.0	Dimensions	4
4.0	Features	5
5.0	Chem-Feed® Matrix	6
6.0	Mounting a pump to the system (single and dual)	7
7.0	Component Identification and Typical Operation - Single Pump	8
7.1	How to Operate the Chem-Feed® Skid System - Single Pump	9
8.0	Component Identification and Typical Operation - Dual Pump	10
8.1	How to operate the Chem-Feed Skid System - Dual Pump	11

# 1.0 Introduction

Congratulations on purchasing the Chem-Feed® Engineered Skid System. The system is designed with the necessary components to safely inject liquid chemical into a system.

Your Chem-Feed® Engineered Skid System is pre-configured based on your selections via the matrix or when designed with our engineering staff.



**Please Note:** Your new Chem-Feed® System has been pressure tested at the factory with clean water for a minimum of four hours before shipping. You may notice trace amounts of clean water in the system. This is part of our stringent quality assurance program at Blue-White Industries.

<u>CAUTION.</u> Skid is provided only for the application and use for which it is intended. User assumes responsibility for proper operation and maintenance. User is responsible for ensuring skid components are compatible with the chemicals being used. Contact the factory if there are any questions regarding use or compatibility.

# 2.0 Specifications

Items listed below are standard available items and ship with most configurations. Your system may be customized with components not listed below.

#### Skid

Chemically resistant polyester powder coated 6061 T6 aluminum. Welded joint construction.

**Pump** (sold separately) FLEXFLO model A1, A2, A3, or A4 peristaltic pumps or CHEM-FEED model CD1, CD3, C2, or C3 diaphragm pump.

#### Piping

PVC Schedule 80 (optional CPVC).

#### Tubing (T)

Reinforced braided PVC, 200 Psi max, certified NSF 51 / NSF 61. The pump inlet and outlet flexible tubing connections are terminated to half unions and secured to the barbed fitting with stainless steel clamps. The calibration cylinder fill

#### **Tubing clamps**

300 series SS band, 400 series SS screw

Unions (U) PVC body, schedule 80, FKM seals

#### Ball valves (V)

Vented ball type, True unions, PVC body, PTFE shaft bearings and seats, FKM seals

#### Pressure Relief Valve (PRV)

PVC body, PTFE primary diaphragm seal. Non-wetted components: FKM secondary seal, zinc plated steel spring, stainless steel external hardware, HDPE pressure adjusting screw and locknut. Infinite adjustment from 5-100 psi. Maximum inlet pressure 150 psi.

#### **Calibration Cylinder (CC)**

PVC body, PVC end caps, 1/4" ID tubing outlet vent. Available volumes: 1.6 GPH (100ml), 4 GPH (250ml), 8 GPH (500ml), 16 GPH (1000ml), 32 GPH (2000ml).

#### **Pulsation Dampener (PD)**

CPVC body,10 cubic inch volume, FKM bladder (optional EPDM bladder)

#### Gauge w/guard (G)

Gauge: liquid filled stainless steel with blowout plug, bottom mount, 1/4" NPT theads. Available pressure ranges: 0-30 psi, 0-100, psi, 0-200 psi. Guard: PVC body, FKM diaphragm seal, temperature compensated oil filled.

#### **Check Valve (CV)**

PVC body, FKM diaphragm (optional EPDM). Cracking pressure: 1.0-1.5 psi. Maximum working pressure: inlet = 150 psi, back = 100 psi.

#### Flow Indicator (F)

Machined cast acrylic, PVC connections, ceramic ball, polypropylene ball stop, PVC half unions, FKM seals (optional EPDM).

#### Y Strainer (S)

PVC body, FKM seals (optional EPDM).

Universal mounting blocks PVC

Pump extended mounting brackets 316 Stainless Steel

#### Skid mounting foot pads 316 Stainless Steel

#### Mounting hardware

18-8 Stainless Steel

#### **Drip Tray**

Polypropylene

Maximum working pressure 150 psig (10.3 bar)

# Operating Temperature

 $14^{\circ}F$  to  $115^{\circ}F$  (-10°C to  $46^{\circ}C$ )

#### Drip Tray

16" x 21" x 3" - 4 gallons total containment

#### Approximate Shipping Weight

Single Pump System: 50 lb. (22.7 Kg) Dual Pump System: 60 lb. (27.2 Kg)

# 3.0 Dimensions

Your Chem-Feed System may be designed differently from drawings below. However, the dimensions shown below remain the same no matter your configuration.

### Single Pump System:



#### **Dual Pump System:**





# 4.0 Features

**Chem-Feed® Engineered Skid Systems** were designed and engineered using solid modeling tools for superior piping installation and easy component maintenance. Custom engineered universal mounting blocks and pre-machined mounting slots provide for easy component servicing and replacement. Each factory built and tested system includes the following standard components:

- **Pressure Relief Valve** Protects the system from over-pressurization, 5-100 psi setting range, 150 psi maximum system pressure. Ships on all systems.
- Check Valve Protects the user from back-flow during pump maintenance. Ships on all systems.
- Flow Verification Sensor S6A accurately verifies chemical feed. Exclusive to Blue-White®.
- Inlet Y Strainer Protects system components from damage cause by dirt or debris.
- Calibration Cylinder Confirm pump output under system conditions. Specify cylinder volumes from 1.6 GPH to 32 GPH.
- **Pulsation Dampener** Protect the system components from pulsation. Recommended for diaphragm pump systems. Not recommended for peristaltic pump systems.
- **Pressure Gage with Guard -** Isolate and protect the system pressure gage. Specify pressure ranges from 0-100psi, or 0-200 psi.
- Mounting Pads Stainless Steel mounting pads to secure Chem-Feed® System to a solid surface. Designed for floor mount or wall mount.
- **Corrosion Resistant** Chem-Feed® frame constructed of chemically resistant polyester powder coated 6061 T6 aluminum. Welded joint construction.

# 5.0 Chem-Feed® Skid System Matrix Model Number Matrix

CFS-1-I

#### **CHEM-FEED® Engineered Skid System - Industrial** CFS-1 Industrial Single pump system - single chemical / single outlet Piping / Valves / Unions / Seal Materials (Verify tubing connection matches pump outlet when ordering) PVC piping, FKM seals, CPVC piping, FKM seals Α Е 1/2" ID PVC braided tubing connections 1/2" ID PVC braided tubing connections PVC piping, EPDM seals, CPVC piping, EPDM seals в F 1/2" ID PVC braided tubing connections 1/2" ID OD PVC braided tubing connections PVC piping, FKM seals, CPVC piping, FKM seals С G 1/4" ID polyethylene tubing connections 1/4" ID Polyethylene tubing connections PVC piping, EPDM seals, CPVC piping, EPDM seals D н 1/4" ID Polyethylene tubing connections 1/4" ID Polyethylene tubing connections Skid frame only without piping Х Structure Assembly Materials Chemical resistant powder coated aluminum stand with 316SS mounting pads Α Chemical Feed Flow Meter Α MS612 chemical feed flow meter with meter mount display, 10-5,000 mL/min (0.158 - 79.2 GPH) в MS622 chemical feed flow meter with meter mount display, 100-10,000 mL/min (1.58 - 158.5 GPH) Х None **PVC** Calibration Cylinder Glass 64 GPH (2000 mL) Α Α в 32 GPH (1000 mL) в Ρ 32 GPH (1000 mL) С 16 GPH (500 mL) С Q 16 GPH (500 mL) 8 GPH (250 mL) D R 6 GPH (200 mL) D Е Е S 3 GPH (100 mL) 3 GPH (100 mL) Х None Pulsation Dampener 10 cubic inch, CPVC body, PTFE Х NONE diaphragm Pressure Gauge w/Guard 200 PSI gauge, PTFE 30 PSI gauge, PTFE С Α diaphragm diaphragm 100 PSI gauge, PTFE в х None diaphragm Pump Isolation Valve (Blank) None

**NOTES:** When ordering pumps for skids, pump head orientation is standard LEFT facing only. Terminal Boxes quoted and mounted separately. All skids are pressure tested prior to shipment. Pumps are purchased and shipped separately. Contact factory for quote/pricing on 5-point performance testing. **Customer is responsible for ensuring skid components are compatible with any chemicals being used.** 

Sample Model Number

Isolation ball shut-off valves at check valve

\*reference Adapter Kits Sheet 85000-198 when ordering with pumps utilizing "M = 1/2"MNPT " or "F = 1/2"FNPT" connections.

Α

Α

Α

Α

Α

CFS-1

Α

Α

# **Model Number Matrix**

# **CHEM-FEED® Engineered Skid System - Industrial**



**NOTES:** When ordering pumps for skids, pump head orientation is standard LEFT facing for right pump, and Right facing for left pump.. Terminal Boxes quoted and mounted separately. All skids are pressure tested prior to shipment. Pumps are purchased and shipped separately. Contact factory for quote/pricing on 5-point performance testing. **Customer is responsible for ensuring skid components are compatible with any chemicals being used.** 

CFS-2-I



# 7.0 Component Identification and Typical Operation - Single Pump Skid



\* PRV = Pressure Relief Valve preset at 50% maximum gauge rating.

# 7.1 How To Operate the Chem-Feed® Skid System - Single Pump Skid

## **Connections:**

Connect chemical solution into either Inlet 1 or inlet 2. (V-1 or V-2)

Connect chemical treated system to outlet. (V-7)

Connect safety vent adapter with 1/4" ID tube from top of calibration cylinder to chemical supply tank.

# To Pump chemical solution into system.

Open ball valve V-1 or V-2, depending on your inlet side.

Close ball valve V-3.

Open ball valve V-4.

Close ball valve V-6.

Open ball valve V-7 to inject chemical solution into your system.

Start pump.

# To calibrate pump / system.

Open ball valve V-1 or V-2, depending on your inlet side.

Close ball valve V-3.

Open ball valve V-4.

Close ball valve V-7.

Open ball valve V-6.

Start pump and run until calibration cylinder is filled to top calibration line. Do not leave pump unattended during this operation.

Stop pump once calibration cylinder is filled.

Close ball valves V-1 and V-2.

Close ball valve V-6.

Open ball valve V-3.

Open ball valve V-4.

Open ball valve V-7 to inject chemical solution into your system.

Note the chemical solution level in the calibration cylinder.

To calibrate pump at maximum speed into your system, Press the prime button on pump. The prime mode runs the pump at maximum speed for 60 seconds (1 minute) on all Blue-White® ProSeries(r) pumps.

To calibrate pump at your desired feed rate, you must pre-program your pump speed before running this routine. Please refer to the instruction manual for your pump to adjust feed rate and additional calibration instructions.



# 8.0 Component Identification and Typical Operation - Dual Pump Skid



# 8.1 How To Operate the Chem-Feed® Skid System - Dual Pump Skid

# **Connections:**

Connect chemical solution into either Inlet 1 or inlet 2. (V-1 or V-2)

Connect chemical treated system to outlet. (V-8)

Connect safety vent adapter with 1/4" ID (3/8" OD) tube from top of calibration cylinder to chemical supply tank.

# To Pump chemical solution into system.

Open ball valve V-1 or V-2, depending on your inlet side.

Close ball valve V-3.

Open ball valve V-4 and / or V5. Depending on your system design.

Close ball valve V-7.

Open ball valve V-8 to inject chemical solution into your system.

# Start pump(s).

# To calibrate pump(s) / system.

Open ball valve V-1 or V-2, depending on your inlet side.

Close ball valve V-3.

Open ball valve V-4 or V5, depending on which pump you're calibrating.

Close ball valve V-8.

Open ball valve V-7. This open valve will direct chemical into calibration cylinder.

Start pump and run until calibration cylinder is filled to top calibration line. Do not leave pump unattended during this operation!

Stop pump once calibration cylinder is filled.

Close ball valves V-1 and V-2.

Close ball valve V-7.

Open ball valve V-3.

Open ball valve V-4 or V5, depending on which pump you're calibrating.

Open ball valve V-8 to inject chemical solution into your system.

Note the chemical solution level in the calibration cylinder.

To calibrate pump at maximum speed into your system, Press the prime button on pump. The prime mode runs the pump at maximum speed for 60 seconds (1 minute) on all Blue-White® ProSeries(r) pumps.

To calibrate pump at your desired feed rate, you must pre-program your pump speed before running this routine. Please refer to the instruction manual for your pump to adjust feed rate and additional calibration instructions.



# 10.0 WARRANTY

### 10.1 Limited Warranty

The skid is a quality product and is warranted for 24 months from date of purchase (proof of purchase is required). The skid will be repaired or replaced at our discretion. The pumps have a separate warranty and are not covered under this warranty.

### 10.2 What is not Covered

- > The pump(s). Refer to pump warranty page for information.
- > Removal, or re-installation, and any related labor charge.
- > Freight to the factory.
- > Skids that have been tampered with, or in pieces.
- > Damage to the skids that results from misuse, carelessness (such as chemical spills) on the enclosure, abuse, lack of maintenance, or alteration that is out of Blue-White's control.
- > Skids damaged by faulty wiring, power surges, or acts of nature.

Blue-White does not assume responsibility for any loss, damage, or expense directly or indirectly related to or arising out of the use of its products. Failure must have occurred due to defect in material or workmanship and not as a result of operation of the product other than in normal operation as defined in the pump operation manual.

The warranty status is determined by the product serial label and the sales invoice or receipt. The serial label must be on the product and be legible. The warranty status of the skid will be verified by Blue-White or a factory authorized service center.

## 10.3 Obtaining In-Warranty Repair

Contact the factory to obtain a RMA (Return Material Authorization) number. Carefully pack the system as instructed. Please enclose a brief description of the problem as well as the original invoice or sales receipt, or copy showing the date of purchase. Prepay all shipping costs. COD shipments will not be accepted. Warranty service must be performed by the factory or an authorized service center. Damage caused by improper packaging is the responsibility of the sender. When In-Warranty repair or replacement is completed, the factory pays for return shipping to the dealer or customer.

## 10.4 Product Use Warning

Blue-White products are manufactured to meet the highest quality standards in the industry. Each product instruction manual includes a description of the associated product warranty and provides the user with important safety information. Purchasers, installers, and operators of Blue-White products should take the time to inform themselves about the safe operation of these products. In addition, Customers are expected to do their own due diligence regarding which products and materials are best suited for their intended applications. Blue-White is pleased to assist in this effort but does not guarantee the suitability of any particular product for any specific application as Blue-White does not have the same degree of familiarity with the application that the customer/end user has. While Blue-White will honor all of its product warranties according to their terms and conditions, Blue-White shall only be obligated to repair or replace its defective parts or products in accordance with the associated product warranties. **BLUE-WHITE SHALL NOT BE LIABLE EITHER IN TORT OR IN CONTRACT FOR ANY LOSS OR DAMAGE WHETHER DIRECT, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL, ARISING OUT OF OR RELATED TO THE FAILURE OF ANY OF ITS PARTS OR PRODUCTS OR <b>OF THEIR NONSUITABILITY FOR A GIVEN PURPOSE OR APPLICATION.** 

## 10.5 Chemical Resistance Warning

Blue-White offers a wide variety of wetted parts. Purchasers, installers, and operators of Blue-White products must be well informed and aware of the precautions to be taken when injecting or measuring various chemicals, especially those considered to be irritants, contaminants or hazardous. Customers are expected to do their own due diligence regarding which products and materials are best suited for their applications, particularly as it may relate to the potential effects of certain chemicals on Blue-White products and the potential for adverse chemical interactions.

Blue-White tests its products with water only. The chemical resistance information included in this instruction manual was supplied to Blue-White by reputable sources, but Blue-White is not able to vouch for the accuracy or completeness thereof. While Blue-White will honor all of its product warranties according to their terms and conditions, Blue-White shall only be obligated to repair or replace its defective parts or products in accordance with the associated product warranties.

BLUE-WHITE SHALL NOT BE LIABLE EITHER IN TORT OR IN CONTRACT FOR ANY LOSS OR DAMAGE, WHETHER DIRECT, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL, ARISING OUT OF OR RELATED TO THE USE OF CHEMICALS IN CONNECTION WITH ANY BLUE-WHITE PRODUCTS.



Users of electrical and electronic equipment (EEE) with the WEEE marking per Annex IV of the WEEE Directive must not dispose of end of life EEE as unsorted municipal waste, but use the collection framework available to them for the return, recycle, recovery of WEEE and minimize any potential effects of EEE on the environment and human health due to the presence of hazardous substances. The WEEE marking applies only to countries within the European Union (EU) and Norway. Appliances are labeled in accordance with European Directive 2002/96/EC.

Contact your local waste recovery agency for a Designated Collection Facility in your area.

5300 Business Drive Huntington Beach, CA 92649 USA

TEL: 714-893-8529 FAX: 714-894-9492 www.blue-white.com sales@blue-white.com customerservice@blue-white.com